

Modelos / Models: G2FS4, G4FD8, G4FD



TAPA QUEMADOR Ø 100 MM  
BURNER COVER, 100 MM  
Cod. BERTOS: 22294500  
Cod. IBERITAL: 40558



CORONA Ø 90 MM  
RING SLOTTED, 100MM  
Cod. BERTOS: 22285300  
Cod. IBERITAL: 40557



TAPA QUEMADOR Ø 80 MM  
BURNER COVER, 80MM  
Cod. BERTOS: 22294100  
Cod. IBERITAL: 40556



BASE QUEMADOR, 80 MM  
LOWER PART, 80MM  
Cod. BERTOS: 22282700  
Cod. IBERITAL: 40572



CORONA, 80 MM  
RING OFFEN, 80MM  
Cod. BERTOS: 22284800  
Cod. IBERITAL: 41305



TERMOPAR, M9X1  
THERMOCOUPLE 600/M9X1  
Cod. BERTOS: 22286900  
Cod. IBERITAL: 41552



ENCENDEDOR  
PIEZOELECTRIC STARTERS  
Cod. BERTOS: 22188300  
Cod. IBERITAL: 40018



TUERCA M8X1  
NUT M8X1  
Cod. BERTOS: 22290900  
Cod. IBERITAL: 40540

Modelos / Models: G2FS4/S, G4FD8/S, G6F12/S, G4S, G6S



TAPA QUEMADOR, 75 MM  
BURNER COVER, 75MM  
Cod. BERTOS: 22293700  
Cod. IBERITAL: 41300



VENTURI, 75 MM  
VENTURI, 75MM  
Cod. BERTOS: 22993300  
Cod. IBERITAL: 41301



BASE QUEMADOR, 75 MM  
BURNER HEAD, 75MM  
Cod. BERTOS: 22280300  
Cod. IBERITAL: 41299

Modelos / Models: G2FS4/S, G4FD8/S, G6F12/S, G4S, G6S (CONTINUACIÓN)



TAPA QUEMADOR, 95 MM  
BURNER COVER, 95MM  
Cod. BERTOS: 22293900  
Cod. IBERITAL: 41303



VENTURI, 95 MM  
VENTURI 95MM  
Cod. BERTOS: 22993400  
Cod. IBERITAL: 41304



BASE QUEMADOR, 95 MM  
BURNER HEAD, 95MM  
Cod. BERTOS: 22280400  
Cod. IBERITAL: 41302



TERMOPAR SIT M9X1 60 CM  
THERMOCOUPLE 600/M9X1  
Cod. BERTOS: 22289200  
Cod. IBERITAL: 40534



ENCENDEDOR  
PIEZOELECTRIC STARTERS  
Cod. BERTOS: 22188300  
Cod. IBERITAL: 40018

Modelos / Models: G7F\_B, G7F\_M, G7F\_, G7FM\_, G9F\_M, G9F



BASE QUEMADOR 3,5KW  
BURNER BASE 3,5 KW  
Cod. BERTOS: 31807200  
Cod. IBERITAL: 41343



BASE QUEMADOR 3,5KW  
BURNER BASE 3,5 KW  
Cod. BERTOS: 31807200  
Cod. IBERITAL: 41343



TAPA QUEMADOR  
BURNER COVER  
Cod. BERTOS: 31954300  
Cod. IBERITAL: 41342



QUEMADOR, 6KW  
BURNER, 6 KW  
Cod. BERTOS: 31807000  
Cod. IBERITAL: 41341

Modelos / Models: G7F2/G7F4/G7F6BE, G7F2/G7F4MC, G7F4/G7F6E, G9F\_ME, G9F\_E



ABRAZADERA  
COUNTER FLANGE, CLAMP  
Cod. BERTOS: 22966200  
Cod. IBERITAL: 40521



CONTACTOR, 2 SALIDAS  
IGNITION UNIT , 2 OUTPUTS  
Cod. BERTOS: 31002400  
Cod. IBERITAL: 40153



CONTACTOR  
IGNITION UNIT , 6 OUTPUTS  
Cod. BERTOS: 31002200  
Cod. IBERITAL: 40152



TERMOPAR SIT M9X1 60 CM  
THERMOCOUPLE, 600 MM  
Cod. BERTOS: 22289200  
Cod. IBERITAL: 40534

VARIOS / VARIOUS



PARRILLA GRUPO B  
TOP GRATE GROUP B  
Cod. BERTOS: 22642300  
Cod. IBERITAL: 41389



PARRILLA GRUPO A  
TOP GRATE GROUP A  
Cod. BERTOS: 22642100  
Cod. IBERITAL: 41390

## COCINAS - TOPE SÓLIDO (COMP. GAS) / OPEN COOKERIES - SOLID TOPS (GAS COMP.)

Modelos / Models: G7TPM, G7TP, G7TP2FM, G7TP2F, G9TP



TERMOPAR SIT M9X1 60 CM  
THERMOCOUPLE, 600MM  
Cod. BERTOS: 22289200  
Cod. IBERITAL: 40534



ENCENDEDOR 10015  
PIEZOELECTRIC STARTERS  
Cod. BERTOS: 32188200  
Cod. IBERITAL: 40468



BUJÍA Ø 6X44 MM  
IGNITER  
Cod. BERTOS: 22296900  
Cod. IBERITAL: 40481

## COCINAS (COMP. ELÉCTRICOS) / OPEN COOKERIES (ELECTRICAL COMP.)

MODELOS / MODELS: SNACK LINE 700 SERIES



PLANCHA ELÉCTRICA  
2600W/240V, 220MM  
HOT PLATE 2600W/240V, 220MM  
Cod. BERTOS: 22037800  
Cod. IBERITAL: 40283



SWITCH 7 POSICIONES  
7 TACT SWITCH  
Cod. BERTOS: 22049900  
Cod. IBERITAL: 41371



PLANCHA ELÉCTRICA  
2600W /240V  
HOT PLATE 2600W/240V,  
220X220MM  
Cod. BERTOS: 22037400  
Cod. IBERITAL: 40880



BOMBILLA SEÑALADORA, 230V  
SIGNAL LAMP  
Cod. BERTOS: 22167900  
Cod. IBERITAL: 41419



PLANCHA ELÉCTRICA  
3500W/240V, 300X300MM  
ELÉCTRIC HOT PLATE,  
3500W/240V, 300X300MM  
Cod. BERTOS: 35037400  
Cod. IBERITAL: 40280



SWITCH 7 POSICIONES  
7-POSITION SWITCH  
Cod. BERTOS: 22049900  
Cod. IBERITAL: 41371



BOMBILLA PILOTO VERDE 230V  
SIGNAL LAMP  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40199

## HORNOS MODULARES (COMP. GAS) / MODULAR OVENS (GAS COMP.)

MODELOS / MODELS: 700 SERIES (FG)



MANDO  
KNOB  
Cod. BERTOS: 31875900  
Cod. IBERITAL: 41459



ETIQUETA PARA MANDO  
SYMBOL RING  
Cod. BERTOS: 31952300  
Cod. IBERITAL: 41460

MODELOS / MODELS: 700-SERIES (FG1)



MANDO NEGRO  
KNOB  
Cod. BERTOS: 31876000  
Cod. IBERITAL: 41181

Modelos / Models: FSG8, FSGN



ENCENDEDOR  
PIEZOELECTRIC IGNITER  
Cod. BERTOS: 22188300  
Cod. IBERITAL: 40018

Modelos / Models: FG



TERMOPAR SIT M9X1 150 CM  
THERMOCOUPLE  
Cod. BERTOS: 31289000  
Cod. IBERITAL: 40362

## HORNOS MODULARES (COMP. ELÉCTRICOS) / MODULAR OVENS (ELECTRICAL COMP.)

Modelos / Models: FCGN, FSD8, FE1



RESISTENCIA 2500W/230V  
HEATING ELEMENT 2500W/230V  
Cod. BERTOS: 22015500  
Cod. IBERITAL: 40820

Modelos / Models: FES, FE1



MOTOR CON VENTILADOR  
45W 220V 50HZ  
MOTOR COMPLETE  
Cod. BERTOS: 23117700  
Cod. IBERITAL: 40927



BOMBILLA PILOTO VERDE 230V  
SIGNAL LAMP/GREEN  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40199



TERMOSTATO  
THERMOSTAT  
Cod. BERTOS: 30064600  
Cod. IBERITAL: 41565



BOMBILLA SEÑALADORA  
AMARILLA, 230V  
SIGNAL LAMP/YELLOW  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197

### MODELOS / MODELS: FCD8



**TERMOSTAR**  
**THERMOSTAT**  
Cod. BERTOS: 22061900  
Cod. IBERITAL: 41560



**ABRAZADERA**  
**RETAINER**  
Cod. BERTOS: 22699200  
Cod. IBERITAL: 40922

### MODELOS / MODELS: 700-SERIES (FES, FE1)



**MANDO NEGRO**  
**KNOB**  
Cod. BERTOS: 31876000  
Cod. IBERITAL: 41181



**ETIQUETA PARA MANDO**  
**SYMBOL RING**  
Cod. BERTOS: 31953500  
Cod. IBERITAL: 41461

### MODELOS / MODELS: FE



**BOMBILLA PILOTO VERDE 230V**  
**SIGNAL LAMP/GREEN**  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40199



**RETENEDOR**  
**RETAINER**  
Cod. BERTOS: 22699200  
Cod. IBERITAL: 40922



**BOMBILLA SEÑALADORA**  
**AMARILLA, 230V**  
**SIGNAL LAMP/YELLOW**  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197



**SWITCH**  
**SWITCH**  
Cod. BERTOS: 22050300  
Cod. IBERITAL: 40702



**TERMOSTATO TRIFASE**  
**100-300°C**  
**THERMOSTAT**  
Cod. BERTOS: 22062600  
Cod. IBERITAL: 40367

### MODELOS / MODELS: 700-SERIES



**MANDO NEGRO**  
**KNOB**  
Cod. BERTOS: 31876000  
Cod. IBERITAL: 41181

**MODELOS / MODELS: UNIVERSAL****PORTA BOMBILLA  
LAMP HOLDER****Cod. BERTOS: 23158600**  
**Cod. IBERITAL: 40203****BOMBILLA E14 15W 230V  
BULB****Cod. BERTOS: 23155100**  
**Cod. IBERITAL: 40735****SWITCH, 230V  
SWITCH****Cod. BERTOS: 22056600**  
**Cod. IBERITAL: 40716****VIDRIO PARA HORNO  
GLASS****Cod. BERTOS: 23160700**  
**Cod. IBERITAL: 41414****HORNOS MODULARES (COMP. MECÁNICOS) / MODULAR OVENS (MECHANICAL COMP.)****MODELOS / MODELS: FSD8, FCD8****SOPORTE  
BODY SECTION****Cod. BERTOS: 22608200**  
**Cod. IBERITAL: 40930****SELLO PUERTA  
DOOR SEAL****Cod. BERTOS: 22594400**  
**Cod. IBERITAL: 41401****BISAGRA DCHA PARA HORNO  
HINGE RIGHT****Cod. BERTOS: 22608100**  
**Cod. IBERITAL: 40933****MODELOS / MODELS: FES, FG****BISAGRA SX PARA HORNO  
HINGE LEFT****Cod. BERTOS: 31802100**  
**Cod. IBERITAL: 40107****SOPORTE  
BODY SECTION****Cod. BERTOS: 31802500**  
**Cod. IBERITAL: 40105****MODELOS / MODELS: FSGN, FCGN, FE1, FG1****SELLO PUERTA  
DOOR SEAL****Cod. BERTOS: 22594200**  
**Cod. IBERITAL: 41398**

MODELOS / MODELS: FE



**BISAGRA DX PARA HORNO**  
**HINGE RIGHT**  
 Cod. BERTOS: 31802000  
 Cod. IBERITAL: 40106

## HORNO COMPLETOS (COMP. GAS) / COMPLETE OVENS (GAS COMP.)

MODELOS / MODELS: FM06G, FM10G, FM20G, FM200G, FM201G



**QUEMADOR**  
**BURNER (BOILER)**  
 Cod. BERTOS: 25278700  
 Cod. IBERITAL: 41283

MODELOS / MODELS: FC06G, FC10G, FC20G



**VÁLVULA ELETTROSIT 3/4" FF**  
**ELETTROSIT GAS VALVE**  
 Cod. BERTOS: 23270900  
 Cod. IBERITAL: 40422

MODELOS / MODELS: UNIVERSAL



**GENERADOR 2 SALIDAS**  
**IGNITION UNIT**  
 Cod. BERTOS: 32164200  
 Cod. IBERITAL: 40151



**BUJÍA Ø 6X44 MM**  
**ELECTRODE**  
 Cod. BERTOS: 23297400  
 Cod. IBERITAL: 40002



**PILOTO QUEMADOR SIT**  
**3 LLAMAS**  
**PILOT BURNER**  
 Cod. BERTOS: 25291400  
 Cod. IBERITAL: 40016



**TERMOPAR**  
**THERMOCOUPLE**  
 Cod. BERTOS: 23288900  
 Cod. IBERITAL: 41550



**VÁLVULA TANDEM**  
**TANDEM VALVE**  
 Cod. BERTOS: 25271500  
 Cod. IBERITAL: 41592



**BUJÍA**  
**ELECTRODE**  
 Cod. BERTOS: 25297600  
 Cod. IBERITAL: 41270



### MODELOS / MODELS: FE1/2



RESISTENCIA 2200W/230V  
HEATING ELEMENT 2200W/230V  
Cod. BERTOS: 23019200  
Cod. IBERITAL: 41597



MOTOR CON VENTILADOR 45W  
220V 50HZ  
MOTOR/COMPLETE  
Cod. BERTOS: 23117700  
23118000  
Cod. IBERITAL: 40927



TERMOSTATO MONOFASE  
50-300°C  
THERMOSTAT  
Cod. BERTOS: 23063600  
Cod. IBERITAL: 40737



BOMBILLA SEÑALADORA  
AMARILLA, 230V  
SIGNAL LAMP/YELLOW  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197



SWITCH  
SWITCH  
Cod. BERTOS: 23050600  
Cod. IBERITAL: 41377



BOMBILLA PILOTO VERDE 230V  
SIGNAL LAMP/GREEN  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40197

### MODELOS / MODELS: FC06E, FC12E



RESISTENCIA 6000W/240V  
HEATING ELEMENT 6000W/240V  
Cod. BERTOS: 23021300  
Cod. IBERITAL: 41596



RESISTENCIA 900W/230V  
HEATING ELEMENT 900W/230V  
Cod. BERTOS: 23016600  
Cod. IBERITAL: 41598



TEMPORIZADOR 120 MIN  
TIMER  
Cod. BERTOS: 23078700  
Cod. IBERITAL: 40404



BOMBILLA SEÑALADORA  
AMARILLA, 230V  
SIGNAL LAMP/YELLOW  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197



MANDO  
KNOB  
Cod. BERTOS: 24653900  
Cod. IBERITAL: 41458

Modelos / Models: FM06E, FM10E, FM20E



RESISTENCIA 4360W/240V  
HEATING ELEMENT 4360 W/240 V  
Cod. BERTOS: 25021600  
Cod. IBERITAL: 41511

Modelos / Models: FM06EDG/GDG



SENSOR (J)  
SENSOR (J)  
Cod. BERTOS: 25918900  
Cod. IBERITAL: 41543

Modelos / Models: FM10/20EDQ FM10/20GDG



SENSOR (J)  
SENSOR (J)  
Cod. BERTOS: 25919500  
Cod. IBERITAL: 41545

Modelos / Models: FC200E, FC401E, FC201E



SWITCH  
SWITCH  
Cod. BERTOS: 25058400  
Cod. IBERITAL: 41484



BOMBILLA SEÑALADORA  
AMARILLA, 230V  
SIGNAL LAMP/YELLOW  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197



MANDO  
KNOB  
Cod. BERTOS: 24653900  
Cod. IBERITAL: 41458

Modelos / Models: FM06EB/GB, FM10EB/GB, FM20EB/GB



**SWITCH SELECTOR**  
**SELECTOR SWITCH**  
Cod. BERTOS: 25051700  
Cod. IBERITAL: 41373



**BOMBILLA PILOTO VERDE 230V**  
**SIGNAL LAMP/GREEN**  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40199



**TERMOSTATO**  
**THERMOSTAT**  
Cod. BERTOS: 23063300  
Cod. IBERITAL: 41558



**BOMBILLA SEÑALADORA**  
**AMARILLA, 230V**  
**SIGNAL LAMP/YELLOW**  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197



**REGULADOR DE ENERGÍA**  
**ENERGY REGULATOR**  
Cod. BERTOS: 27114900  
Cod. IBERITAL: 40310



**SWITCH**  
**SWITCH**  
Cod. BERTOS: 25058400  
Cod. IBERITAL: 41484



**MANDO**  
**KNOB**  
Cod. BERTOS: 24653900  
Cod. IBERITAL: 41458

Modelos / Models: FM200EB/GB, FM201EB/GB, FM401EB/GB



**MANDO**  
**KNOB**  
Cod. BERTOS: 24653900  
Cod. IBERITAL: 41458



**SWITCH**  
**SWITCH**  
Cod. BERTOS: 25058400  
Cod. IBERITAL: 41484

Modelos / Models: MM06EB/EG, MM10EB/EG, MM20EB/EG



**MANDO**  
**KNOB**  
Cod. BERTOS: 24653900  
Cod. IBERITAL: 41458



**BOMBILLA SEÑALADORA**  
**AMARILLA, 230V**  
**SIGNAL LAMP/YELLOW**  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197



**SWITCH**  
**SWITCH**  
Cod. BERTOS: 25058400  
Cod. IBERITAL: 41484

### MODELOS / MODELS: FC\_EDG, FC\_GDG



**SENSOR**  
**SENSOR**  
Cod. BERTOS: 24076500  
Cod. IBERITAL: 41584

### MODELOS / MODELS: FC\_E



**SWITCH SELECTOR**  
**SELECTOR SWITCH**  
Cod. BERTOS: 23050900  
Cod. IBERITAL: 41372



**REGULADOR DE ENERGÍA**  
**ENERGY REGULATOR**  
Cod. BERTOS: 27114900  
Cod. IBERITAL: 40310



**TERMOSTATO**  
**THERMOSTAT**  
Cod. BERTOS: 23900600  
Cod. IBERITAL: 41558

### MODELOS / MODELS: MM2/3



**TERMOSTATO DE SEGURIDAD**  
**SAFETY THERMOSTAT**  
Cod. BERTOS: 25069800  
Cod. IBERITAL: 41564



**RELÉ**  
**RELAY**  
Cod. BERTOS: 25080600  
Cod. IBERITAL: 41495



**TERMOSTATO**  
**THERMOSTAT**  
Cod. BERTOS: 25070800  
Cod. IBERITAL: 41566



**MOTOR**  
**MOTOR**  
Cod. BERTOS: 25118000  
Cod. IBERITAL: 41443

### MODELOS / MODELS: UNIVERSAL



**TRANSFORMADOR 230/12V 3VA**  
**TRANSFORMER**  
Cod. BERTOS: 25164500  
Cod. IBERITAL: 41583



**VIDRIO PARA HORNO**  
**GLASS**  
Cod. BERTOS: 25589200  
Cod. IBERITAL: 41427

MODELOS / **MODELS:** UNIVERSAL (CONTINUACIÓN)

**SWITCH**  
**SWITCH**  
 Cod. BERTOS: 25058400  
 Cod. IBERITAL: 41484



**ENCAPSULADO**  
**HOUSING**  
 Cod. BERTOS: 25806900  
 Cod. IBERITAL: 41426



**PORTA BOMBILLA E14**  
**LAMP HOLDER**  
 Cod. BERTOS: 25159500  
 Cod. IBERITAL: 41417



**BOMBILLA HORNO E14**  
 25W 220/230V  
**BULB**  
 Cod. BERTOS: 23155300  
 Cod. IBERITAL: 40204



**JUNTA PORTABOMBILLA EN**  
**SILICONA**  
**GASKET**  
 Cod. BERTOS: 25597400  
 Cod. IBERITAL: 41428



**PORTA BOMBILLA**  
**LAMP HOLDER**  
 Cod. BERTOS: 23158600  
 Cod. IBERITAL: 40203



**BOMBILLA E14 15W 230V**  
**LAMP**  
 Cod. BERTOS: 23155100  
 Cod. IBERITAL: 40735



**JUNTA**  
**GASKET**  
 Cod. BERTOS: 23602800  
 Cod. IBERITAL: 41415



**MICROINTERRUPTOR 10A 250V**  
**MICRO SWITCH**  
 Cod. BERTOS: 23060600  
 Cod. IBERITAL: 40219



**TIMBRE, 230V**  
**BUZZER, 230 V**  
 Cod. BERTOS: 25079300  
 Cod. IBERITAL: 41546



**ELECTROVÁLVULA 329**  
 220/240V Ø 10 MM  
**SOLENOID VALVE, SINGLE**  
 Cod. BERTOS: 23116200  
 Cod. IBERITAL: 40149



**BOMBA DE DRENAJE**  
**DRAIN PUMP**  
 Cod. BERTOS: 25115600  
 Cod. IBERITAL: 41387

MODELOS / MODELS: UNIVERSAL (CONTINUACIÓN)



**ELECTRO VÁLVULA 349 220/240V**  
**Ø 10 MM**  
**SOLENOID VALVE, DOUBLE**  
**Cod. BERTOS: 23116900**  
**Cod. IBERITAL: 40150**

MODELOS / MODELS: \_05\_ \_06\_



**VENTILADOR**  
**FAN WHEEL, 0180MM**  
**Cod. BERTOS: 24646500**  
**Cod. IBERITAL: 41431**

MODELOS / MODELS: \_10\_ \_201\_



**VENTILADOR**  
**FAN WHEEL, 0300MM**  
**Cod. BERTOS: 24646900**  
**Cod. IBERITAL: 41444**

MODELOS / MODELS: FCO5E



**MOTOR 0015HP**  
**MOTOR, 0,15 HP**  
**Cod. BERTOS: 23118300**  
**Cod. IBERITAL: 41430**

MODELOS / MODELS: FC05



**SELLOS PARA PUERTA**  
**COMPLETO 420X645MM**  
**DOOR SEAL COMPLETE**  
**420 X 645 MM**  
**Cod. BERTOS: 23595800**  
**Cod. IBERITAL: 41631**



**SELLOS 1700MM**  
**SEALS 1700MM**  
**Cod. BERTOS: 23601400**  
**Cod. IBERITAL: 41633**

## MODELOS / MODELS: FCO5E

**SOPORTE PARA PUERTA**  
**BODY CATCH****Cod. BERTOS: 24577700**  
**+ 24579500****Cod. IBERITAL: 41547**

## MODELOS / MODELS: FCO6

**SELLOS PARA PUERTA**  
**COMPLETO 480X700MM**  
**DOOR SEAL COMPLETE**  
**480 X 700MM****Cod. BERTOS: 23595200**  
**Cod. IBERITAL: 41632****SENSOR (PT100)****SENSOR (PT100)****Cod. BERTOS: 25919100****Cod. IBERITAL: 41544**

## MODELOS / MODELS: FC12/20, FM10/20

**SELLOS 2250MM****SEALS 2250MM****Cod. BERTOS: 23602100****Cod. IBERITAL: 41634**

## MODELOS / MODELS: FC12/20, MM 12/20, FM10/20EB/GB

**SENSOR (PT100)****SENSOR (PT100)****Cod. BERTOS: 25919300****Cod. IBERITAL: 41540**

## MODELOS / MODELS: \_2/3\_

**MANILLA****HANDLE****Cod. BERTOS: 25605100****Cod. IBERITAL: 41475****CASQUILLO****PIN****Cod. BERTOS: 25906400****Cod. IBERITAL: 41478**

**MODELOS / MODELS: \_2/3\_ (CONTINUACIÓN)****DISCO  
DISC****Cod. BERTOS: 25938600****Cod. IBERITAL: 41477****SOPORTE PARA PUERTA  
DOOR CATCH****Cod. BERTOS: 25779200****Cod. IBERITAL: 41479****MUELLE  
SPRING****Cod. BERTOS: 25884200****Cod. IBERITAL: 41476****MODELOS / MODELS: UNIVERSAL****SOPORTE PARA PUERTA  
DOOR CATCH****Cod. BERTOS: 25760000****Cod. IBERITAL: 41470****MECANISMO CENTRAL  
GEARBOX****Cod. BERTOS: 25878100****Cod. IBERITAL: 40269****CIERRE DCHA-IZQ. SIN  
CERRADURA 791 CR  
DOOR CATCH****Cod. BERTOS: 23579700****Cod. IBERITAL: 40938****MICROINTERRUPTOR  
MICRO SWITCH****Cod. BERTOS: 33059200****Cod. IBERITAL: 41434****MODELOS / MODELS: MM2/3****SELLO PARA PUERTA DE VIDRIO  
DOOR SEAL 1110MM****Cod. BERTOS: 25594000****Cod. IBERITAL: 41400**



Modelos / Models: GFLS4, GFRS4, GFRM6, GFLD8, GFMD8



ENCENDEDOR  
PIEZOELECTRIC IGNITER  
Cod. BERTOS: 22188300  
Cod. IBERITAL: 40018



BUJÍA Ø 6X44 MM  
ELECTRODE  
Cod. BERTOS: 22296800  
Cod. IBERITAL: 40481



PILOTO QUEMADOR  
PILOT BURNER  
Cod. BERTOS: 22291200  
Cod. IBERITAL: 40472

Modelos / Models: G7FL4B, G7FR4B, G7FL8B, G7FR8B, G7FM8B, G7FL4M, G7FR4M, G7FL8M, G7FR8M, G7FM8M,



GRIFO TERMOSTATICO PEL25ST  
GAS THERMOSTAT, PEL25ST  
Cod. BERTOS: 22274500  
Cod. IBERITAL: 40496



ETIQUETA PARA MANDO  
SYMBOL RING  
Cod. BERTOS: 31952300  
Cod. IBERITAL: 41460

Modelos / Models: G7F\_, G9F\_



PILOTO QUEMADOR 3 LLAMAS  
PILOT BURNER  
Cod. BERTOS: 27291100  
Cod. IBERITAL: 40473



ENCENDEDOR 10015  
PIEZOELECTRIC IGNITER  
Cod. BERTOS: 32188200  
Cod. IBERITAL: 40468



BUJÍA Ø 6X44 MM  
ELECTRODE  
Cod. BERTOS: 22296800  
Cod. IBERITAL: 40481

Modelos / Models: EFLS4, EFRS4, EFRS4, EFRM6, EFLD8, EFMD8



RESISTENCIA, 1350W  
HEATING ELEMENT, 1350W  
Cod. BERTOS: 22039300  
Cod. IBERITAL: 41513



TERMOSTATO TRIFASE  
100-300°C  
THERMOSTAT, 3-POLE, 300°C  
Cod. BERTOS: 22062600  
Cod. IBERITAL: 40367



BOMBILLA SEÑALADORA, 230V  
SIGNAL LAMP, 230 V  
Cod. BERTOS: 22167900  
Cod. IBERITAL: 41419



RETENEDOR  
RETAINER  
Cod. BERTOS: 22699200  
Cod. IBERITAL: 40922



BOMBILLA SEÑALADORA  
AMARILLA, 380V  
YELLOW INDICATOR LAMP, 380V  
Cod. BERTOS: 22167800  
Cod. IBERITAL: 41418



SWITCH  
SWITCH  
Cod. BERTOS: 22050300  
Cod. IBERITAL: 40702

Modelos / Models: E7F



RESISTENCIA, 1350W  
HEATING ELEMENT, 1350W  
Cod. BERTOS: 22039300  
Cod. IBERITAL: 41513

Modelos / Models: E7F\_, E9F\_



BOMBILLA SEÑALADORA  
AMARILLA, 230V  
SIGNAL LAMP, YELLOW, 230V  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197



RETENEDOR  
RETAINER  
Cod. BERTOS: 22699200  
Cod. IBERITAL: 40922



BOMBILLA PILOTO VERDE 230V  
SIGNAL LAMP, GREEN, 230 V  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40199



SWITCH  
SWITCH  
Cod. BERTOS: 22050300  
Cod. IBERITAL: 40702



TERMOSTATO TRIFASE  
100-300°C  
THERMOSTAT, 3-POLE, 300°C  
Cod. BERTOS: 22062600  
Cod. IBERITAL: 40367

**GRILLAS PIEDRA VOLCÁNICA (COMP. GAS) / LAVA ROCK GRILLS (GAS COMP.)**Modelos / **MODELS:** PLG40, PLG80, PLG40M, PLG80M, G9PL**QUEMADOR  
BURNER**Cod. BERTOS: 31278400  
Cod. IBERITAL: 41284**BUJÍA Ø 6X44 MM  
ELECTRODE**Cod. BERTOS: 22296900  
Cod. IBERITAL: 40481**TERMOPAR SIT M9X1 60 CM  
THERMOCOUPLE, 600MM**Cod. BERTOS: 22289200  
Cod. IBERITAL: 40534**ENCENDEDOR 10015  
PIEZOELECTRIC IGNITER**Cod. BERTOS: 32188200  
Cod. IBERITAL: 40468**PILOTO QUEMADOR 3 LLAMAS  
PILOT BURNER**Cod. BERTOS: 27291100  
Cod. IBERITAL: 40473**BARBACOAS (COMP. GAS) / CHARGRILLS (GAS COMP.)**Modelos / **MODELS:** EGRS4, EGRM6**RESISTENCIA, 1500W/230V  
HEATING ELEMENT 1500W/230V**Cod. BERTOS: 22039100  
Cod. IBERITAL: 41512**VARIOS / VARIOUS****BOMBILLA SEÑALADORA, 230V  
LAMP, 12MM, 230V, GREEN**Cod. BERTOS: 22167900  
Cod. IBERITAL: 41419**BOMBILLA SEÑALADORA  
AMARILLA, 380V  
YELLOW INDICATOR LAMP, 380V**Cod. BERTOS: 22167800  
Cod. IBERITAL: 41418

## MARMITAS (COMP. ELÉCTRICOS) / BRATT PANS (ELECTRICAL COMP)

Modelos / Models: EBR54



**BOMBILLA SEÑALADORA, 230V**  
**SIGNAL LAMP, 230 V**  
 Cod. BERTOS: 22167900  
 Cod. IBERITAL: 41419



**RETENEDOR**  
**RETAINER**  
 Cod. BERTOS: 22699200  
 Cod. IBERITAL: 40922



**BOMBILLA SEÑALADORA**  
**AMARILLA, 380V**  
**YELLOW INDICATOR LAMP, 380V**  
 Cod. BERTOS: 22167800  
 Cod. IBERITAL: 41418



**SWITCH**  
**SWITCH**  
 Cod. BERTOS: 22050300  
 Cod. IBERITAL: 40702



**TERMOSTATO TRIFASE**  
**100-300°C**  
**THERMOSTAT**  
 Cod. BERTOS: 22062600  
 Cod. IBERITAL: 40367

## BAÑO DE MARÍA (COMP. ELÉCTRICOS) / BAINS MARIE (ELECTRICAL COMP.)

Modelos / Models: EBMS4, EBMD8, E7BM4B, E7BM8B



**RESISTENCIA, 1600W/230V**  
**HEATING ELEMENT 1600W/230V**  
 Cod. BERTOS: 22038900  
 Cod. IBERITAL: 41514



**BOMBILLA SEÑALADORA, 230V**  
**GREEN, 230V**  
 Cod. BERTOS: 22167900  
 Cod. IBERITAL: 41419



**THERMOSTAT 120°C**  
**THERMOSTAT**  
 Cod. BERTOS: 22062400  
 Cod. IBERITAL: 41557



**BOMBILLA SEÑALADORA**  
**AMARILLA, 230V**  
**YELLOW, 230V**  
 Cod. BERTOS: 30168500  
 Cod. IBERITAL: 40197



**SWITCH, 230V**  
**ROCKER SWITCH, 230 V**  
 Cod. BERTOS: 22056600  
 Cod. IBERITAL: 40716

### VARIOS / VARIOUS



RESISTENCIA 650W/230V  
**CERAMIC HEATER 650W**  
 Cod. BERTOS: 22016100  
 Cod. IBERITAL: 40798



SWITCH, 230V  
**MAIN SWITCH RED**  
 Cod. BERTOS: 22056600  
 Cod. IBERITAL: 40716



RESISTENCIA 350W/230V  
**HEATING ELEMENT 350W/230V**  
 Cod. BERTOS: 22016400  
 Cod. IBERITAL: 41529

## FREIDORAS (COMP. GAS) / FRYERS (GAS COMP.)

### MODELOS / MODELS: GL10B4, GL10 + 10MB6



TERMOPAR SIT M9X1 60 CM  
**THERMOCOUPLE**  
 Cod. BERTOS: 22289200  
 Cod. IBERITAL: 40534



BOMBILLA SEÑALADORA  
 AMARILLA, 380V  
**YELLOW INDICATOR LAMP, 380V**  
 Cod. BERTOS: 22167800  
 Cod. IBERITAL: 41418



SWITCH, 230V  
**SWITCH, 230 V**  
 Cod. BERTOS: 22056600  
 Cod. IBERITAL: 40716

### MODELOS / MODELS: GL8B, GL8 + 8B, GL10B, GL10 + 10B, GL10M, GL10 + 10M, GL20M, GL20 + 20M, 9GL\_



PILOTO QUEMADOR 3 LLAMAS  
**PILOT BURNER**  
 Cod. BERTOS: 27291100  
 Cod. IBERITAL: 40473



ENCENDEDOR 10015  
**PIEZOELECTRIC IGNITER**  
 Cod. BERTOS: 32188200  
 Cod. IBERITAL: 40468



BUJÍA Ø 6X44 MM  
**ELECTRODE**  
 Cod. BERTOS: 22296900  
 Cod. IBERITAL: 40481

Modelos / Models: E10B4, E10 + 10MB6



**BOMBILLA SEÑALADORA, 230V**  
**SIGNAL LAMP, 230 V**  
 Cod. BERTOS: 22167900  
 Cod. IBERITAL: 41419



**CONMUTADOR ANGULAR**  
**SWITCH**  
 Cod. BERTOS: 22050400  
 Cod. IBERITAL: 40708



**BOMBILLA SEÑALADORA**  
**AMARILLA, 380V**  
**YELLOW INDICATOR LAMP, 380V**  
 Cod. BERTOS: 22167800  
 Cod. IBERITAL: 41418



**TERMOSTATO DE SEGURIDAD**  
**SAFETY THERMOSTAT**  
 Cod. BERTOS: 22069400  
 Cod. IBERITAL: 40780



**TERMOSTATO**  
**THERMOSTAT**  
 Cod. BERTOS: 22062900  
 Cod. IBERITAL: 41571



**CESTA FREIDORA**  
**FRYER BASKET**  
 Cod. BERTOS: 22617400  
 Cod. IBERITAL: 41359



**RETENEDOR**  
**RETAINER**  
 Cod. BERTOS: 22699200  
 Cod. IBERITAL: 40922

Modelos / Models: E7F10-4B, E7F10-4B, E7F10-8B, E7F10-8BS, E7F10-4M, E7F10-4MS, E7F10-8M, E7F10-8MS



**MICROINTERRUPTOR**  
**MICRO SWITCH**  
 Cod. BERTOS: 33059200  
 Cod. IBERITAL: 41434



**BOMBILLA PILOTO AMARILLA**  
**230V**  
**SIGNAL LAMP, 230 V**  
 Cod. BERTOS: 33171100  
 Cod. IBERITAL: 40210



**BOMBILLA PILOTO VERDE 230V**  
**SIGNAL LAMP, 230V**  
 Cod. BERTOS: 33171000  
 Cod. IBERITAL: 40201

## SARTENES BASCULANTES (COMP. GAS) / TILTING BRATT PANS (GAS COMP.)

MODELOS / MODELS: G7BR8



GRIFO TERMOSTATICO PEL25ST  
**GAS THERMOSTAT**  
 Cod. BERTOS: 22274500  
 Cod. IBERITAL: 40496



PILOTO QUEMADOR 3 LLAMAS  
**PILOT BURNER**  
 Cod. BERTOS: 27291100  
 Cod. IBERITAL: 40473



MANDO  
**KNOB**  
 Cod. BERTOS: 31875900  
 Cod. IBERITAL: 41459



BUJÍA Ø 6X44 MM  
**ELECTRODE**  
 Cod. BERTOS: 22296900  
 Cod. IBERITAL: 40481



ETIQUETA PARA MANDO  
**SYMBOL RING**  
 Cod. BERTOS: 31952300  
 Cod. IBERITAL: 41460



ENCENDEDOR  
**PIEZOELECTRIC IGNITER**  
 Cod. BERTOS: 22188300  
 Cod. IBERITAL: 40018

MODELOS / MODELS: G9BR8



PILOTO QUEMADOR SIT  
 3 LLAMAS  
**PILOT BURNER**  
 Cod. BERTOS: 25291400  
 Cod. IBERITAL: 40016



BUJÍA Ø 6X44 MM  
**ELECTRODE**  
 Cod. BERTOS: 23297400  
 Cod. IBERITAL: 40002

## SARTENES BASCULANTES (COMP. ELÉCTRICOS) / TILTING BRATT PANS (ELECTRICAL COMP.)

MODELOS / MODELS: E7BR8



BOMBILLA SEÑALADORA  
 AMARILLA, 230V  
**SIGNAL LAMP YELLOW**  
 Cod. BERTOS: 30168500  
 Cod. IBERITAL: 40197



BOMBILLA PILOTO VERDE 230V  
**SIGNAL LAMP GREEN**  
 Cod. BERTOS: 30168800  
 Cod. IBERITAL: 40199

MODELOS / MODELS: E7BR8, E9BR8



TERMOSTATO TRIFASE  
 100-300°C  
**THERMOSTAT 3-POLE**  
 Cod. BERTOS: 22062600  
 Cod. IBERITAL: 40367



TERMOSTATO MONOFASE  
 50-300°C  
**THERMOSTAT 1-POLE**  
 Cod. BERTOS: 23063600  
 Cod. IBERITAL: 40737

### MODELOS / MODELS: E9BR8



BOMBILLA SEÑALADORA  
AMARILLA, 380V  
YELLOW INDICATOR LAMP, 380V  
Cod. BERTOS: 33170900  
Cod. IBERITAL: 41418



BOMBILLA SEÑALADORA, 400V  
SIGNAL LAMP GREEN 400 V  
Cod. BERTOS: 22167900  
Cod. IBERITAL: 41419

## MARMITAS (COMP. GAS) / BOILING PANS (GAS COMP.)

### MODELOS / MODELS: G9P\_



PILOTO QUEMADOR SIT  
3 LLAMAS  
PILOT BURNER  
Cod. BERTOS: 25291400  
Cod. IBERITAL: 40016



TERMOPAR SIT M9X1 150 CM  
THERMOCOUPLE  
Cod. BERTOS: 31289000  
Cod. IBERITAL: 40362



ENCENDEDOR  
PIEZOELECTRIC IGNITER  
Cod. BERTOS: 22188300  
Cod. IBERITAL: 40018

### MODELOS / MODELS: G7PD



BUJÍA Ø 6X44 MM  
ELECTRODE  
Cod. BERTOS: 22296800  
Cod. IBERITAL: 40481

### MODELOS / MODELS: G7PI



TERMOSTATO DE SEGURIDAD  
SAFETY THERMOSTAT  
Cod. BERTOS: 31290200  
Cod. IBERITAL: 41581



MODELOS / MODELS: E7PT



TERMOSTATO DE SEGURIDAD  
SAFETY THERMOSTAT  
Cod. BERTOS: 31290200  
Cod. IBERITAL: 41581

## PEQUEÑA MAQUINARIA Y DISPOSITIVOS SIMPLES / SMALL APPLIANCES AND SINGLE DEVICES

TOSTADORAS / TOASTERS

MODELOS / MODELS: 4TO



RESISTENCIA 800W/230V  
HEATING ELEMENT 800W/230V  
Cod. BERTOS: 30031600  
Cod. IBERITAL: 41508

MODELOS / MODELS: 4TO, 6T, 8T



REJILLA PINZA  
PLIER  
Cod. BERTOS: 30611300  
Cod. IBERITAL: 40928



TEMPORIZADOR, 15 MIN  
TIMER, 15MIN  
Cod. BERTOS: 30082100  
Cod. IBERITAL: 41589

MODELOS / MODELS: 6T, 8T



RESISTENCIA 500W/115V  
HEATING ELEMENT 500W/115V  
Cod. BERTOS: 30040800  
Cod. IBERITAL: 41509



TUBO DE CUARZO  
QUARTZ TUBE  
Cod. BERTOS: 30043100  
Cod. IBERITAL: 41503

MODELOS / MODELS: 8T



SWITCH  
SWITCH  
Cod. BERTOS: 30051600  
Cod. IBERITAL: 41352

### Modelos / Models: PS , PD



RESISTENCIA 700W/230V  
HEATING ELEMENT 700W/230V  
(UPPER)

Cod. BERTOS: 30022500  
Cod. IBERITAL: 41504



RESISTENCIA 1000W/230V  
HEATING ELEMENT 1000W/230V  
(LOWER)

Cod. BERTOS: 30023500  
Cod. IBERITAL: 41505

### Modelos / Models: PM



RESISTENCIA 1000W/230V  
HEATING ELEMENT 1000W/230V  
(UPPER)

Cod. BERTOS: 30024100  
Cod. IBERITAL: 41506



RESISTENCIA 1500W/230V  
HEATING ELEMENT 1500W/230V  
(LOWER)

Cod. BERTOS: 30024300  
Cod. IBERITAL: 41507

### Modelos / Models: PS\_ PD\_ PDT\_ PM\_ PMT\_



BOMBILLA SEÑALADORA  
AMARILLA, 230V  
SIGNAL LAMP, 230V  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197



ETIQUETA PARA MANDO  
SYMBOL RING  
Cod. BERTOS: 31953500  
Cod. IBERITAL: 41461




BOMBILLA PILOTO VERDE 230V  
SIGNAL LAMP, 230V  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40199



TERMOSTATO  
THERMOSTAT  
Cod. BERTOS: 30064600  
Cod. IBERITAL: 41565

## SALAMANDRAS / SALAMANDERS

### Modelos / Models: SA/E68M, SA/E68M-E, SA/E60, SA/E60-E



RESISTENCIA 1600W/230V  
HEATING ELEMENT 1600W/230V  
Cod. BERTOS: 27022300  
Cod. IBERITAL: 41518



MANDO  
KNOB  
Cod. BERTOS: 27653300  
Cod. IBERITAL: 41452



REGULADOR DE ENERGÍA  
ENERGY REGULATOR  
Cod. BERTOS: 27114900  
Cod. IBERITAL: 40310



BOMBILLA PILOTO VERDE 230V  
SIGNAL LAMP  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40199

Modelos / Models: ELT4B, ELT4 + 4B,



RESISTENCIA 1800W/230V  
HEATING ELEMENT 1800W/230V  
Cod. BERTOS: 33024600  
Cod. IBERITAL: 41530

Modelos / Models: ELT8B, ELT8 + 8B



RESISTENCIA 2700W/230V  
HEATING ELEMENT 2700W/230V  
Cod. BERTOS: 33024700  
Cod. IBERITAL: 41531

Modelos / Models: ELT10B, ELT10 + 10B,



RESISTENCIA 3100W/230V  
HEATING ELEMENT 3100W/230V  
Cod. BERTOS: 33024800  
Cod. IBERITAL: 41532

Modelos / Models: ELT12, ELT12 + 12B,



RESISTENCIA 3100W/230V  
HEATING ELEMENT 3500W/230V  
Cod. BERTOS: 33025600  
Cod. IBERITAL: 41533

Modelos / Models: ELT\_B, ELT12M



TERMOSTATO DE SEGURIDAD  
SAFETY THERMOSTAT  
Cod. BERTOS: 33070300  
Cod. IBERITAL: 41579



BOMBILLA PILOTO VERDE 230V  
SIGNAL LAMP, 230 V  
Cod. BERTOS: 30168800  
Cod. IBERITAL: 40199



BOMBILLA SEÑALADORA  
AMARILLA, 230V  
SIGNAL LAMP, 230 V  
Cod. BERTOS: 30168500  
Cod. IBERITAL: 40197

## MODELOS / MODELS: ELTB-E, ELTM-E



**BOMBILLA PILOTO VERDE 400V**  
**SIGNAL LAMP, 400 V**  
Cod. BERTOS: 33171000  
Cod. IBERITAL: 40201



**BOMBILLA PILOTO AMARILLA 400V**  
**SIGNAL LAMP, 400 V**  
Cod. BERTOS: 33171100  
Cod. IBERITAL: 40210

## MODELOS / MODELS: ELTB,



**TERMOSTATO**  
**THERMOSTAT, 1-POLE**  
Cod. BERTOS: 33065600  
Cod. IBERITAL: 41573

## MODELOS / MODELS: ELT4



**CESTA 4 LTS**  
**BASKET, 4 LTS**  
Cod. BERTOS: 33613800  
Cod. IBERITAL: 41360