



**BISAGRA DERECHA HORNO
BAGUETERO**
RIGH HINGE
Cod. SMEG: 931330249
Cod. IBERITAL: 43424



SOPORTE BISAGRA DERECHA
RIGHT HINGE SUPPORT
Cod. SMEG: 685970043
Cod. IBERITAL: 43427



**BISAGRA IZQUIERDA HORNO
BAGUETERO**
LEFT HINGE
Cod. SMEG: 931330250
Cod. IBERITAL: 43425



SOPORTE BISAGRA IZQUIERDA
RIGHT HINGE SUPPORT
Cod. SMEG: 685970027
Cod. IBERITAL: 43426



BISAGRA PUERTA HORNO ALFA 41
DOOR HINGE
Cod. SMEG: 931330461
Cod. IBERITAL: 43471



MANDO
TERMOSTATO+CONMUTADOR
HORNO SME
TIMER KNOB WITH COMMUTATOR
Cod. SMEG: 754131105
Cod. IBERITAL: 43466



MANDO TEMPORIZADOR ALFA 200
TIMER KNOB
Cod. SMEG: 764971805
Cod. IBERITAL: 43467



TERMOSTATO HORNO 230V
MECÁNICO
THERMOSTAT 230 V
(MECHANICAL)
Cod. SMEG: 948800080
Cod. IBERITAL: 43464



TEMPORIZADOR HORNO ALFA41T
TIMER
Cod. SMEG: 685970027
Cod. IBERITAL: 43035



TERMOSTATO HORNO 300° 230V
CLASICO
THERMOSTAT 230 V / 300°
(CLASSIC)
Cod. SMEG: 818731124
Cod. IBERITAL: 43460



INTERRUPTOR GENERAL 230V
HORNO CLASSIC S
GENERAL SWITCH 230V
Cod. SMEG: 811730241
Cod. IBERITAL: 43459



TERMOSTATO SEGURIDAD 230V
HORNO ALFA31T
SAFETY THERMOSTAT
Cod. SMEG: 818730541
Cod. IBERITAL: 43034



JUNTA PUERTA HORNO ALFA 31T
GASKET
Cod. SMEG: 754130861
Cod. IBERITAL: 43036



JUNTA PUERTA HORNO
BAGUETERO
GASKET
Cod. SMEG: 754131105
Cod. IBERITAL: 43423