



IBERITAL DE RECAMBIOS S.A.

FIG.	COD.	DESCRIPCION	DESCRIPTION	FIG.	COD.	DESCRIPCION	DESCRIPTION
1	12997	DOSIFICAD. ABRILLANTADOR	RINSAID PUMP				
5	8344	EJE BOMBA	ADJUSTMENT SCREW				
6	8350	JUNTA TÓRICA 2012	O-RING 2012				
7	12592	JUNTA TÓRICA	O-RING				
8	12593	MUELLE	SPRING				
9	8359	GUÍA MUELLE DOSIFICADOR	PUMP SPRING GUIDE				
10	8294	MEMBRANA DOSIFICADOR	DOSIMETER MEMBRANE				
11	8361	KIT RACOR DOSIFICADOR	RINSAID VALVE CONNEC. KIT				
12	12379	JUNTA TÓRICA	O-RING				
13	1832	VÁLVULA ABRILLANTADOR ANTIGUA	OLD RINSAID VALVE				
13	5994	VÁLVULA ABRILL. MODERNA	NEW RINSAID VALVE				
14	12380	ARANDELA DENTADA Ø12mm	LOCK WASHER Ø12mm				
15	12762	TUERCA CIERRE BOMBA	PUMP LOCK NUT				