



IBERITAL DE RECAMBIOS S.A.

FIG.	COD.	DESCRIPCION	DESCRIPTION	FIG.	COD.	DESCRIPCION	DESCRIPTION
1	13050	JUNTA TERMOSTATO CUBA	GASKET TANKTHERMOSTAT	23	13238	TUBO BC..HR	HOSE BC..HR
2	6461	TERMOSTATO CUBA	TANK THERMOSTAT	24	13219	TUBO LAVADO SUPERIOR/INFERIOR	UPPER/LOWER WASH HOSE
3	13214	REBOSADERO BR-BC-FC43	OVERFLOW PIPE BR-BC-FC43	25	13230	ESCUADRA	BRACKET
4	13226	JUNTA REBOSADERO BR-BC-FC43	GASKET OVERFLOW PIPE BR-BC-FC43	26	13209	PRESOSTATO 60-40 BC-BR-FC43	PRESSURE SWITCH 60-40 BC-BR-FC43
5	13215	FILTRO ASPIRACIÓN BR-BC-FC43	SUCTION FILTER BR-BC-FC43	27	13174	BRIDA PRESIÓN Ø8,3/7,8mm	ELASTIC CLAMP Ø8,3/7,8mm
6	13236	MUELLE FIJAC. FILTRO CUBA BR-BC	RETAIN SPRING FOR FILTER BR-BC	28	13212	TUBO CAMPANA PRESOSTATO BC	HOSE AIR CHAMBER BC
7	13229	FILTRO CUBA BR-BC-FC43	TANK FILTER BR-BC-FC43	29	13234	ABRAZADERA	CLAMP
8	13208	RESIST. CUBA 1275W 230V BR-BC	1275W 230V HEAT ELEMENT BR-BC	30	13235	ABRAZADERA 39,7X 37,7	CLAMP 39,7X 37,7
9	13034	JUNTA RESISTENCIA CUBA SERIE B	O-RING	31	13211	CAMPANA PRESOS. BC-BR	AIR CHAMBER BC-BR
10	13043	TAPÓN CODO SUP. LAV.	PLUG F/UPPER WASH ARM SUPP.	32	13228	CONTRA TUERCA	NUT FOR AIR TRAP
11	13055	JUNTA TÓRICA Ø2,62X20,63mm	O-RING Ø2,62X20,63mm	33	13227	JUNTA CAMPANA PRESOSTATO	GASKET AIR TRAP
12	13047	CODO SUP. LAVADO/ACLARADO	UPPER WASH/RINSE ARM SUPPORT	34	14737	TUBO SALIDA AGUA BR	OUTLET HOSE BR PUMP
13	6527	JUNTA Ø46,99X5,33X57,6mm	O-RING Ø46,99X5,33X57,6mm	35	13221	TUBO ASPIRAC. BOMBA BR-BC-FC43	DELIVERY HOSE BR-BC-FC43
14	13217	SOPORTE INF. ASPAS LAV. BC-FC43	LOWER WASH ARM SUPP. BC-FC43	36	13220	TUBO SALIDA AGUA BC-FC43	OUTLET HOSE BC-FC43 PUMP
15	13224	ARO TÓRICO 82,22X87,46X2,62	O-RING 82,22X87,46X2,62	37	13059	ABRAZADERA 32-44 H=12,2	CLAMP 32-44 H=12,2
16	13223	JUNTA SOP. BRAZO LAVADO BC-FC	GASKET WASH ARM SUPP. BC-FC	39	6352	BOMBA 0,3HP 220-240V 2229	PUMP 0,3HP 220-240V 50Hz 2229
17	13054	JUNTA SOPORTE INFERIOR PEQ.	O-RING	39	6369	BOMBA HP 0,2 220/240-50Hz	PUMP 0,2HP 220-240V 50Hz
18	13218	TUBO ACLARADO	RINSE HOSE	40	13210	BRIDA CUBA ASPIRACIÓN BR-BC-FC	LOCK NUT SUCTI. FLANGE BR-BC-FC
19	13216	CODO INF. LAV. BT-BC-FC43	LOWER ELBOW WASH BT-BC-FC43	41	13222	TUBO DESAGÜE BR-BC-FC43	DRAIN HOSE BR-BC-FC43
20	13232	ABRAZADERA 26-38 H=12,2	CLAMP 26-38 H=12,2	42	13225	JUNTA CUBA ASPIRAC. BR-BC-FC43	GASKET SUCTION BASIN BR-BC-FC43
21	13233	ABRAZADERA 38-50 H=12,2	CLAMP 38-50 H=12,2	43	13213	CUBA ASPIRACIÓN/DESA. BR-BC-FC	SUCTION BASIN BR-BC-FC43
22	13231	ABRAZADERA 15-24 H=12,5	CLAMP 15-24 H=12,5	44	6423	JUNTA 1 1/2"	GASKET DRAIN 1 1/2"
23	13049	TUBO 13X20	PIPE	45	13035	CONTRATUERCA 1"	LOCK NUT 1"

