



IBERITAL DE RECAMBIOS S.A.

FIG.	COD.	DESCRIPCION	DESCRIPTION	FIG.	COD.	DESCRIPCION	DESCRIPTION
1	23960	FILTRO ANTIPARASITARIO	ANTI-NOISE FILTER	23	23967	GUÍA MUELLE	SPRING GUIDE
2	3388	CONDENSADOR 10µF	10µF CAPACITOR	24	23968	TUERCA	NUT
2	6036	CONDENSADOR 12,5 µF / 450 VAC	12,5 µF/450 VAC CAPACITOR	25	23969	JUNTA	GASKET
3	23508	PRESOSTATO 40-18	40-18 PRESSURE SWITCH	26	23970	BOLA	BALL
4	23514	PROGRAMADOR CICLO	CYCLE TIMER	27	23971	TUERCA	NUT
5	23518	RELÉ TODOS MODELOS	ALL MODELS RELAY	28	23985	SOPORTE GUÍA	GUIDE SUPPORT
6	23961	CORONA PROGRAMADOR	CROWN TIMER	29	23986	MUELLE SOPORTE	SUPPORT SPRING
7	23519	CONTACTOR	CONTACTOR	30	23987	CUERPO SOPORTE	SUPPORT BODY
8	23532	TERMOSTATO SEGURIDAD	SAFETY THERMOSTAT	31	23990	TORNILLO	SCREW
9	23533	TERMOSTATO CALDERÍN	BOILER THERMOSTAT	32	23973	ESCUADRA PUERTA	DOOR SQUARE
10	23530	TERMOSTATO CUBA	TANK THERMOSTAT	33	23976	PERNO PUERTA	DOOR BOLT
11	23977	PIE MÁQUINA	MACHINE FOOT	34	23979	MANETA PUERTA DS101-103	DS101-103 DOOR HANDLE
12	23517	PROGRAMADOR REGENERACIÓN	REGENERATION TIMER	34	23980	MANETA PUERTA DS201-203	DS201-203 DOOR HANDLE
13	23952	BOTONERA DOBLE	DOUBLE PUSH BUTTON	35	23982	LATERAL DERECHO MANETA PUERTA	DOOR HANDLE RIGHTH SIDE
14	24098	BOTONERA TRIPLE	TRIPLE PUSH BUTTON	36	23983	LATERAL IZQ MANETA PUERTA	DOOR HANDLE LEFT SIDE
15	23956	FUNDA PILOTO	WARNING LAMP COVER	37	24100	VOLANTE	ROTATING PLATE
16	23955	LÁMPARA PILOTO	PILOTE LAMP	38	24101	EJE VOLANTE	ROTATING PLATE ROD
17	23991	MANDO PROGRAMADOR	TIMER COMMAND	39	24102	ARANDELA VOLANTE	ROTATING PLATE WASHER
18	24099	PULSADOR VERDE	GREEN PUSH BUTTON	40	24103	TUERCA	NUT
19	23957	JUNTA	GASKET	41	24104	SOPORTE VOLANTE	ROTATING PLATE SUPPORT
20	23959	MICRO PUERTA	DOOR MICROSWITCH	42	23989	GANCHO PUERTA	DOOR HOOK
21	23965	TUERCA	NUT	43	23972	PARAGOLPES	DOOR STOP
22	23966	MUELLE	SPRING	44	23988	PLETINA	PLATE