



IBERITAL DE RECAMBIOS S.A.

FIG.	COD.	DESCRIPCION	DESCRIPTION	FIG.	COD.	DESCRIPCION	DESCRIPTION
1	12997	DOSIFICAD. ABRILLANTADOR	RINSAID PUMP				
4	8351	TORNILLO 3,9X13	SCREW 3,9X13				
5	8344	EJE BOMBA	ADJUSTMENT SCREW				
6	8350	JUNTA TÓRICA 2012	O-RING 2012				
7	8358	JUNTA TÓRICA	O-RING				
8	12761	MUELLE	SPRING				
9	8359	GUÍA MUELLE DOSIFICADOR	PUMP SPRING GUIDE				
10	8294	MEMBRANA DOSIFICADOR	DOSIMETER MEMBRANE				
11	8353	RACOR ASPIRACIÓN	SUCTION CONNECTION				
12	12378	RACOR ENVÍO	OUTLET CONNECTION				
13	12379	JUNTA TÓRICA	O-RING				
14	1832	VÁLVULA ABRILLANTADOR ANTIGUA	OLD RINSAID VALVE				
14	5994	VÁLVULA ABRILL. MODERNA	NEW RINSAID VALVE				
15	12380	ARANDELA DENTADA Ø12mm	LOCK WASHER Ø12mm				
16	12762	TUERCA CIERRE BOMBA	PUMP LOCK NUT				
17	12382	ABRAZADERA	CLAMP				
18	8342	TUERCA M 10	NUT M- 10				
25	12384	PRESOSTATO 28-12 +-5	28-12 +-5 PRESSURE SWITCH				
27	6108	RACOR ENLACE PRESOSTATO	PRESSURE FITTING				
28	6146	JUNTA TÓRICA	O-RING				
29	6109	JUNTA PLANA Ø38X25X2mm	FLAT RUBBER GASKET Ø38X25X2mm				
30	13005	DOSIFICAD. ABRILLANTADOR	RINSAID PUMP				