

Modelos / Models: EKB120, EKB150



**JUNTA PARA MANDO**  
**GASKET**  
Cod. AMBACH: 5017314030  
Cod. IBERITAL: 42361



**TARJETA ELECTRÓNICA**  
**DISPLAY P.C.B.**  
Cod. AMBACH: 5062909870  
Cod. IBERITAL: 42476



**MANDO ELECTRICO Ø 72 MM**  
**KNOB**  
Cod. AMBACH: 5022914031  
Cod. IBERITAL: 42387



**PANTALLA FRONTAL**  
**FRONT FOIL**  
Cod. AMBACH: 5011814552  
Cod. IBERITAL: 42486



**ETIQUETA PARA MANDO 50-300°C**  
**SYMBOL**  
Cod. AMBACH: 5022914339  
Cod. IBERITAL: 42378

Modelos / Models: KBHE70, TPE70, KME50, KME90, KHE90



**TERMOSTATO TRIFASE 360°C**  
**SAFETY THERMOSTAT**  
Cod. AMBACH: 5061603684  
Cod. IBERITAL: 42160



**MANDO 50-300°C**  
**KNOB**  
Cod. AMBACH: 5022904315  
Cod. IBERITAL: 42388



**LAMPARA SEÑALADORA**  
**AMARILLA 400V**  
**SIGNAL LAMP**  
Cod. AMBACH: 5061103271  
5061103275  
5061109899  
Cod. IBERITAL: 42370



**TERMOSTATO MONOFASE**  
**50-320°C**  
**THERMOSTAT + SWITCH**  
Cod. AMBACH: 5061602948  
Cod. IBERITAL: 42415

Modelos / Models: EKM50, EKB120, EKB150



**TERMOSTATO TRIFASE 360°C**  
**SAFETY THERMOSTAT (UNTIL**  
**10'03)**  
Cod. AMBACH: 5061603684  
5061616223  
Cod. IBERITAL: 42160



**LAMPARA SEÑALADORA**  
**AMARILLA 230V**  
**SIGNAL LAMP/YELLOW**  
Cod. AMBACH: 5061109898  
Cod. IBERITAL: 42366