



IBERITAL DE RECAMBIOS S.A.

FIG.	COD.	DESCRIPCION	DESCRIPTION	FIG.	COD.	DESCRIPCION	DESCRIPTION
1	21067	TAPA TOLVA T48	T48 HOPPER LID	20	33020	BOQUILLA	NOZZLE
2	21068	TOLVA T48	T48 HOPPER	21	33021	CUBETA	BUCKET
3	21012	PASADOR TOLVA	HOPPER LOCK	22	33022	BOQUILLA COMPLETA	COMPLETE NOZZLE
4	21069	PORTAFRESAS SUPERIOR	CUTTINGHOLDER	23	33024	MOTOR T48 220V	MOTOR T48 220V
5	12287	FRESA FIORENZATO 83/45/3A	FIORENZATO BLADES 83	24	33025	MUELLE SUJECIÓN CUBETA	HOLDING BUCKET SPRING
6	21071	PORTAFRESAS INFERIOR	CUTTINGHOLDER				
7	21072	CONO DE SEGURIDAD	SAFETY CONE				
8	21073	COJINETE MOTOR	MOTOR BALL BEARING				
9	21074	TAPA MOTOR	MOTOR LID				
10	21024	HORQUILLA	FORK				
11	21075	PIE	GRINDER FOOT				
12	21025	CONDENSADOR 16µF	16µF CONDENSER				
12	21026	CONDENSADOR 50µF	50µF CONDENSER				
12	21078	CONDENSADOR 20µF	20µF CONDENSER				
13	21030	CONTACTOR 380V	380V STARTER RELAY				
13	21031	CONTACTOR 220V	220V STARTER RELAY				
14	21076	REGULACIÓN MICROMETRICA	MICRO ADJUSTMENT				
15	21077	TAPA INFERIOR	LOWER LID				
16	21021	INTER. BIPOLAR VERDE	GREEN BIPOLAR SWITCH				
16	21022	FUNDA INTERRUPTOR	SWITCH COVER				
17	21079	TOLVA T48 COMPLETA	HOPPER COMPLETE				
18	33019	PALANCA	LEVER				
19	21020	MUELLE TRINQUETE CIERRE	SPRING				