

	COD.	DESCRIPCIÓN / DESCRIPTION		COD.	DESCRIPCIÓN / DESCRIPTION
	14438	<p>TERMOSTATO REARME FI-80-100-120</p> <p>REARMAMENT THERMOSTAT FI-80-100-120</p>		12597	<p>TERMOSTATO 50-58° C-CR D/STS43-48-53-60/DP35-40-45-50</p> <p>THERMOSTAT 50-58° C-CR D/STS43-48-53-60/DP35-40-45-50</p>
	423	FUTURMAT		30527	<p>TERMOSTATO BIMETALICO DOBLE 55-42° C-CR D/STS43-48-53-60/DP35-40-45-50</p> <p>BIMETALLIC DOUBLE THERMOSTAT 55-42° C-CR D/STS43-48-53-60/DP35-40-45-50</p>
		<p>TERMOSTATO CALDERIN 90° LT-4-5/LP-14</p> <p>BOILER THERMOSTAT 90° LT-4-5/LP-14</p>			
	423	HOONVED		30552	<p>TERMOSTATO 90° BULBO 45° TR2 C6</p> <p>THERMOSTAT 90° BULB 45° TR2 C6</p>
		<p>TERMOSTATO CALDERIN 90° E-36-40-43-50/CM-43-48/NK-52-60 TS-48</p> <p>BOILER THERMOSTAT 90° E-36-40-43-50/CM-43-48/NK-52-60 TS-48</p>			
	12328	<p>TERMOSTATO 30-90° C-3-4/C-CR D</p> <p>THERMOSTAT 30-90° C-3-4/C-CR D</p>		23367	<p style="text-align: center;">IME - OMNIWASH</p> <p>TERMOSTATO CALDERIN 95° TODOS MODELOS</p> <p>BOILER THERMOSTAT 95° ALL MODELS</p>
	12594	<p>TERMOSTATO 105° C-CR D/STS43-48</p> <p>THERMOSTAT 105° C-CR D/STS43-48</p>		23368	<p>TERMOSTATO CUBA 55° TODOS MODELOS</p> <p>TANK THERMOSTAT 55° ALL MODELS</p>
	12598	<p>TERMOSTATO SEGURIDAD 90-110° 53-60 C-CR D/STS43-48-53-60/DP35-40-45-50 APS APSE/C90-81/SP81/ED550</p> <p>SAFETY THERMOSTAT 90-110° 53-60 C-CR D/STS43-48-53-60/DP35-40-45-50 APS APSE/C90-81/SP81/ED550</p>		2025	<p style="text-align: center;">JEMI</p> <p>TERMOSTATO GS-3-4-8-9-82-100</p> <p>THERMOSTAT GS-3-4-8-9-82-100</p>
	12330	<p>TERMOSTATO FIJO 56° C-3-4/UNI 43-48-53-60 STS43-48-53-60/DP35-40-45-50</p> <p>FIXED THERMOSTAT 56° C-3-4/UNI 43-48-53-60 STS43-48-53-60/DP35-40-45-50</p>		423	<p style="text-align: center;">LINEA BLANCA</p> <p>TERMOSTATO 90° LC-80-1000-1500-1700-2000-2300 LC2600-2800-3500-4000 36/1200-1800/300-3000-600</p> <p>THERMOSTAT 90° LC-80-1000-1500-1700-2000-2300 LC2600-2800-3500-4000 36/1200-1800/300-3000-600</p>