



IBERITAL DE RECAMBIOS S.A.

FIG.	COD.	DESCRIPCION	DESCRIPTION	FIG.	COD.	DESCRIPCION	DESCRIPTION
1	30703	PLACA ELECTR. LFD/ST/E SOFTSTART	LFD/ST/E ELECTRONIC BOARD	27	12397	CONTACTOR CN5-10 220V	CONTACTOR CN5-10 220V
2	10675	INTERRUPTOR CM UNIP. NA	SWITCH BUTTON	37	12492	PROGRAMA. 120 - 04-98 -	TIMER 120- 04-98-
3	10674	PULSADOR UNIPOLAR	PUSH BUTTON	39	12384	PRESOSTATO 28-12 +-5	28-12 +-5 PRESSURE SWITCH
4	12486	SOPORTE	SUPPORT	40	12456	TAPÓN ROSCADO	PLUG
5	12487	BOTÓN PULSADOR	POLISHED GREY KEY	41	12457	JUNTA TÓRICA	O-RING
6	12488	PILOTO NEÓN VERDE	NEON GREEN LAMP	42	12458	TUERCA CIERRE TAPÓN CUBA	TANK CAP LOCK NUT
7	8341	PILOTO INTERRUPTOR	SWITCH LAMP	43	12467	JUNTA BISAGRA	DOOR SUPPORT RUBBER
8	12493	PILOTO AZUL 230V	230V BLUE LAMP	44	12319	TOPE BISAGRA	DOOR STOP
9	12327	SOPORTE PILOTO	LAMP HOLDER	45	12463	TORNILLO 4X10	SCREW 4X10
10	12490	FUNDA VERDE	GREEN LAMP COVER	46	11621	CIERRE PUERTA	DOOR CLOSE
11	12326	FUNDA PILOTO NARANJA	ORANGE LAMP COVER	47	12655	TAPÓN M-10	CAP M-10
12	12494	FUNDA AZUL NUEVA	NEW BLUE LAMP COVER	48	12656	TUERCA PLÁSTICO M10	PLASTIC NUT M10
13	30704	CABLE CONEXIÓN	WIRE CONNECTION	49	12657	JUNTA PLANA	FLAT RUBBER GASKET
14	6104	PROGRAMADOR 120	TIMER 120	50	12393	PIE	FOOT
15	12653	FILTRO ANTI INTERFERENCIAS	INTERFERENCE FILTER	51	12323	TOPE CESTA 25mm	BASKET STOP 25mm
16	30705	PLACA ELECTRÓNICA	ELECTRONICS BOARD	52	12597	TERMOSTATO DOBLE	DOUBLE THERMOSTAT
17	12535	TUERCA AUTOBLOQUEANTE	LOCK NUT	53	12596	JUNTA TERMOSTATO	THERMOSTAT GASKET
18	12775	RETÉN PARA TIRANTE PUERTA	DOOR BRACE SEAL	54	12329	MANDO	KNOB
19	12534	ARANDELA PLANA	FLAT WASHER	55	12328	TERMOSTATO 30-90°C	THERMOSTAT 30-90°C
20	12484	RELÉ 16A - 31-12-97	RELAY 16A - 31-12-97	56	12594	TERMOSTATO BIPOLAR 105°C	BIPOLAR THERMOSTAT 105°C
21	12764	PERNO PARA TIRANTE PUERTA	DOOR BRACE BOLT	57	12330	TERMOSTATO 56°C 1,5m	THERMOSTAT 56°C 1,5m
22	30727	PLACA ELECTRÓNICA LFD	LFD ELECTRONICS BOARD	58	12598	TERMOSTATO 110°C 53-60	THERMOSTAT 110°C 53-60